

Instructions for Use

Thermostrip® DS Dishwasher Temperature Strips

Thermostrip® DS is a slotted strip that is designed to be secured on to a utensil or rack, reducing the risk of the strip falling off during a wash cycle yet easily removed and attached to a batch record. Using Thermostrip® DS in a dishwasher with each wash cycle will indicate that the proper sanitation temperature has been reached.

How to Use

- Attach Thermostrip DS to a utensil or tray by wrapping around (item or rack grill) and sliding the color bar through the slit in the strip
- Place tray/utensil with attached strip in dishwasher and run dishwasher
- Read strip Strip color bar will turn to bright orange when the water temperature reaches rated temperature.
- Remove strip and attach to dishwasher documentation