



## Advanced Thermographic Technologies

**Type:** Chill Checker Indicator, Circular, Self-Adhesive  
**Size:** 32mm diameter by 6mm deep (1.25" by 0.23" deep)  
**Print:** 2 Colours. Blue Print onto White Background  
**Events:** 1  
**Temperatures:** in °F and °C, +/-1°C accurate

Type 1	-17°C/+1°F
2	-8°C/+18°F
3	-5°C/+23°F
4	-2°C/+28°F
5	+5°C/+41°F
6	+9°C/+48°F
7	+17°C/+63°F
8	+20°C/+68°F

### Applications:

- ◆ Hand Activated

### Directions for Use:

1. Remove silicone release paper and apply to subject being measured.
2. Cool below specified rating 60 minutes before activating.
3. To activate push the centre of the convex surface.

N.B. Chill Checkers can be cooled below the specified rating, by using a chiller or freezer. When cooled they can be applied to the product and activated.

### Indication:

After a short duration not exceeding five minutes, staining of white paper occurs when the specified temperature rating has been exceeded.

Should the temperature be constantly kept above the specified rating, then complete staining will occur.

Should the product be re-frozen, discoloration will cease, and restart when the rating has been exceeded.

### Standard Packaging: Sold in Boxes of 100 Main Application:

To control and identify problematic temperature conditions that are experienced in transportation of goods, using a low cost method for instance for medical supplies, or to increase food protection in transit to warehouse or depots.