

## Thermostrip® Dishwasher Labels

### Instructions for Use:

Surface Temperature Disinfection Indicator

Thermostrip® DL is a self-adhering waterproof color-changing label that measures the surface temperature of dishware in dish washing machines. Using Thermostrip® DL on a dish surface with each wash cycle will indicate that the proper sanitation temperature has been reached.

### How to Use:

- Attach to the thickest clean dry dish
- Place labeled dish/utensil in dishwasher and run dishwasher
- Read label – Label will turn from silver to black when surface temperature reaches rated temperature
- Remove label and attach to dishwasher documentation