

Thermocapture™

Dishwasher Disinfection Temperature Labels Smartphone App Captures & Records Pass / Fail Data

Thermocapture™ DL is a *personalized* self-adhering, waterproof, color-changing label that measures the surface temperature of dishware in dishwashers. Using Thermocapture™ DL on a dish surface with each wash cycle will provide evidence that the proper dishwasher temperature has been reached during washing.

Thermocapture™ App will photograph the irreversible temperature label capturing your information including the pass / fail color change and upload data and images to your password protected web page.



Features

- **Adhesive Backed Label** ½" x 1 ¾"
- **140°F / 60°C to 180°F / 82°C Temperature Range**
- **Accurate to 1°C**
- **Proof for HACCP Compliance**



Simple Set Up

- We create a label to your specifications
- Download Thermocapture App for any Smartphone
 - We send you an invite code
 - Register Company and label with invite code
 - Create a secure password

Ready to Go

- Affix label to a dish and run through a wash cycle
- Photograph Label with App at the end of cycle
 - Capture QR Code Identifier
 - App qualifies it as pass or fail (label will turn from silver to black indicating pass)
 - Tags record with location and time
 - Stores recorded data / image for client access

That's it. Data is stored on your smartphone and on your password protected page, where images and data can be viewed or downloaded for validation purposes.

Visit Hallcrest.com or call us to further explore how this exciting technology might work for you !