

Reebok CCM ice hockey skates use a temperature label to ensure a custom fit

Reebok CCM in Canada was introducing a new line of ice hockey skates featuring a custom fit and wanted to add a temperature indicator to the skates to ensure that the U Foam foot form technology they were incorporating into the skates is used correctly. Skates would be heated, softening the U Foam allowing the user's foot shape to be molded into the skate.

- **Requirement:** Reebok CCM required a label that would give an indication to the seller that the skates reached the ideal fitting temperature. Label needed to be on the skates during the heating process.
- **Solution:** LCR developed a unique liquid crystal thermometer that covered the requested temperature range, measured surface temperature accurately, was easy to read and cost effective.
- **Product Details**
 - 3 event Liquid Crystal Thermometer
 - 2.50" x .50"
 - Temp range covered: 90-180°F, 30°F increments
 - Permanent grade adhesive
 - Supplied in packs of 100 pieces
 - Colors: Black, White and Red
- **Benefits**
 - Actual individual skate temperature displayed for the seller and user
 - Fitting at proper temperature ensured best fit for the user
 - Solidified them as an industry leader introducing new technology with a commitment to quality



For further information contact sal@hallcrest.com or visit www.hallcrest.com and let us show you what we can do!

SM1402 Rev00

LCRHallcrest is an international manufacturer of color and chemical changing temperature measurement labels, indicators and graphics with in-house design, development and manufacturing capability that offers solutions for unique temperature identification problems.